RCS Hy-Q

Hydraulic scale for forklift trucks and reach trucks

BENEFITS

- High accuracy hydraulic scale
- Less sensitive to load center point eccentricity
- Overload indication in display
- Use in combination with rotators and clamps
- Suitable for rough applications
- Intuitive full color graphic display guides the user
- No manifold block: easy and cost efficient installation



Top quality

Indestructible













FUNCTIONS

- Manual zero correction
- Self-learning zero correction
- Gross/Net weighing (by tare weighing or preset tare entry)
- Total function with five separate registers that can be named by the operator
- Overload indication, based on actual hydraulic pressure, not on calculated weight
- Error message in display

STANDARD SPECIFICATIONS

Capacity 2,500, 5,000 or 10,000 kg

Graduation
2 kg at 2,500 kg capacity
5 kg at 5,000 kg capacity

10 kg at 10,000 kg capacity


System tolerance 0.2% of the scale capacity

Display Grafic full-color display

Keyboard 9 keys

Protection class
IP65 / NEMA 4

Power supply
12Vdc, from truck battery



SYSTEM PACKAGE

- Hy-Q indicator with graphic display
- RAM indicator mounting support
- Oil pressure sensor
- Metal strip with 2 sensors for mast mounting
- Magnet, to be installed on the carriage plate
- Installation- and calibration manual
- Operator manual

HOW RCS HY-Q WORKS

Two sensors in a metal strip mounted against the mast measure the lifting and lowering speed of the forks. While the load passes the trajectory between the two sensors, the indicator samples the hydraulic pressure output of the sensor approximately 1000 times and calculates an average value. The weighing is done UP and DOWN: the load is lifted, and then lowered past the two sensors within a predefined speed bandwidth.

Warning: the 0.2% tolerance can only be guaranteed when the truck mast is in good condition.

((



• ISO 9001 • ISO 1400

OPTIONS*

- Power convertor 80/72/48/36/24 Vdc 12 Vdc
- RS232 output for printer or data transfer (only 1 port available)
- Thermal or matrix printer in separate housing
- Bluetooth or WiFi output
- WeighScan data collector with built-in 1D barcode scanner
- CubeTape digital dimensioning tape
- Level switch to indicate forklift mast tilt position at display

RAVAS Europe B.V.

P.O. Box 2023, NL-5300 CA Zaltbommel, The Netherlands T. +31 (0)418 51 52 20, F. +31 (0)418 51 53 20 backoffice@ravas.com, www.ravas.com

